

AMASADORAS AE-10 / AE-22 / AE-32

SPIRAL MIXERS AE-10 / AE-22 / AE-32

PÉTRINS À SPIRALE AE-10 / AE-22 / AE-32

N.	Denominación	Description	Dénomination	Cod.
1a	Tapa superior AE-10	Upper cover AE-10	Couvercle superieur AE-10	SL1103
1b	Tapa superior AE-22	Upper cover AE-22	Couvercle superieur AE-22	SL0002
1c	Tapa superior AE-32	Upper cover AE-32	Couvercle superieur AE-32	SL0061
2	Microrruptor	Microswitch	Microrrupteur	6502281
3	Moyu Stop	Stop moyu	Moyeu stop	SL0035
4	Excéntrico	Excentric	Excentrique	SL0036
5a	Proteción lateral AE-10	Side protection AE-10	Protection latérale AE-10	SL1445
5b	Proteción lateral AE-22	Side protection AE-22	Protection latérale AE-22	6502323
5c	Proteción lateral AE-32	Side protection AE-32	Protection latérale AE-32	6502327
6a	Barra amasado AE-10	Rod AE-10	Barre AE-10	SL1108
6b	Barra amasado AE-22	Rod AE-22	Barre AE-22	SL0013
6c	Barra amasado AE-32	Rod AE-32	Barre AE-32	SL0071
7	Rodillo caldero AE-22/AE-32	Bowl roll AE-22/AE-32	Rouleau cuve AE-22/AE-32	6502270
8	Conj. patas (4)	Feet set (4)	Ensemble pieds (4)	6500925
9a	Cable conexión trifásico	Three phase connection cable	Câble de connexion triphasé	SL1841
9b	Cable conexión monofásico	Single phase connection cable	Câble de connexion monophasé	SL1671
10	Pulsador parada	Stop switch	Interrupteur d'arrêt	SL0807
11	Pulsador marcha	Start switch	Interrupteur de marche	6502325
12	Tapa mandos	Controls cover	Couvercle commandes	6502231
13	Junta tapa mandos	Controls cover basket	Joint de couvercle commandes	SL0396
14a	Tapa trasera AE-10	Back cover AE-10	Panneau arrière AE-10	SL1114
14b	Tapa trasera AE-22	Back cover AE-22	Panneau arrière AE-22	SL0045
14c	Tapa trasera AE-32	Back cover AE-32	Panneau arrière AE-32	SL0095
15a	Rejilla protectora AE-10	Protecting grid AE-10	Grille protectrice AE-10	6500998
15b	Rejilla protectora AE-22	Protecting grid AE-22	Grille protectrice AE-22	SL0006
15c	Rejilla protectora AE-32	Protecting grid AE-32	Grille protectrice AE-32	SL0065
16a	Caldero AE-10	Bowl AE-10	Cuve AE-10	SL1106
16b	Caldero AE-22	Bowl AE-22	Cuve AE-22	SL0009
16c	Caldero AE-32	Bowl AE-32	Cuve AE-32	6502232
17a	Cadena AE-10	Chain AE-10	Chaîne AE-10	6502230
17b	Cadena AE-22	Chain AE-22	Chaîne AE-22	6502225
17c	Cadena AE-32	Chain AE-32	Chaîne AE-32	6502205
18	Piñon	Pinion	Pignon	6502259
19a	Soporte gancho AE-10/AE-22	Hook support AE-10/AE-22	Support crochet AE-10/AE-22	6502346
19b	Conj. soporte AE-32	Support set AE-32	Ensemble support AE-32	SA4100
20a	Rodamiento AE-10/AE-22	Bearing AE-10/AE-22	Roulement AE-10/AE-22	2600285
20b	Rodamiento AE-32	Bearing AE-32	Roulement AE-32	6502336
21	Chaveta	Key	Clavette	SL0010
22a	Gancho AE-10	Hook AE-10	Crochet AE-10	6502250
22b	Gancho AE-22	Hook AE-22	Crochet AE-22	6502255
22c	Gancho AE-32	Hook AE-32	Crochet AE-32	6502260
23a	Soporte caldero AE-10/AE-22	Bowl holder AE-10/AE-22	Support cuve AE-10/AE-22	6502341
23b	Soporte caldero AE-32	Bowl holder AE-32	Support cuve AE-32	6501243
24a	Rodamiento AE-10/AE-22	Bearing AE-10/AE-22	Roulement AE-10/AE-22	2600285

SPIRAL MIXERS AE-10 / AE-22 / AE-32


PÉTRINS À SPIRALE AE-10 / AE-22 / AE-32

N.	Denominación	Description	Dénomination	Cod.
24b	Rodamiento AE-32	Bearing AE-32	Roulement AE-32	SL0073
240 24c	Rodamiento AE-10/AE-22	Bearing AE-10/AE-22	Roulement AE-10/AE-22	SL0073 SL0131
24d	Rodamiento AE-32	Bearing AE-32	Roulement AE-32	SL0101
25a	Corona AE-10	Crowin gear AE-10	Couronne AE-10	6502205
25b	Corona AE-22/AE-32	Crowin gear AE-22/AE-32	Couronne AE-22/AE-32	6501175
26a	Eje de corona AE-10/AE-22	Crowin gear shaft AE-10/AE-22	Axe couronne AE-10/AE-22	6502241
26b	Eje de corona AE-32	Crowin gear shaft AE-32	Axe couronne AE-32	6502241
27a	Cadena AE-10	Chain AE-10	Chaîne AE-10	6502210
27b	Cadena AE-22	Chain AE-22	Chaîne AE-22	6502215
27c	Cadena AE-32	Chain AE-32	Chaîne AE-32	6502205
28a	Motor trifásico AE-10	Motor III AE-10	Moteur triphasé AE-10	6502294
28b	Motor monofásico AE-10	Motor II AE-10	Moteur monophasé AE-10	6502288
28c	Motor trifásico AE-22	Motor III AE-22	Moteur triphasé AE-22	6502296
28d	Motor monofásico AE-22	Motor II AE-22	Moteur monophasé AE-22	6502282
28e	Motor trifásico AE-32	Motor III AE-32	Moteur triphasé AE-32	6502298
28f	Motor monofásico AE-32	Motor II AE-32	Moteur monophasé AE-32	6502292
29a	Reductor AE-10	Reducer AE-10	Réducteur AE-10	6502340
29b	Reductor AE-22	Reducer AE-22	Réducteur AE-22	6502332
29c	Reductor AE-32	Reducer AE-32	Réducteur AE-32	6502334
30a	Chaveta (corona AE-10)	Key (crowin gear AE-10)	Clavette (couronne AE-10)	SL0043
30b	Chaveta (corona AE-22/AE-32)	Key (crowin gear AE-22/AE-32)	Clavette (couronne AE-22/AE-32)	SL0047
31	Chaveta	Key	Clavette	SL0819
32	Piñon	Pinion	Pignon	6502263
33a	Eje transmisión AE-10	Transmission shaft AE-10	Axe transmission AE-10	6502247
33b	Eje transmisión AE-22	Transmission shaft AE-22	Axe transmission AE-22	6502249
33c	Eje transmisión AE-32	Transmission shaft AE-32	Axe transmission AE-32	6502241
34a	Soporte AE-10/AE-22	Holder AE-10/AE-22	Support AE-10/AE-22	6502348
34b	Soporte AE-32	Holder AE-32	Support AE-32	6502347
35	Placa electrónica AE-10/AE-22/AE-32	Electronic plate AE-10/AE-22/AE-32	Plaqué electronique AE-10/AE-22/AE-32	SL0883
36a	Cableado trifásico AE-10/AE-22/AE-32	Wiring three phase AE-10/AE-22/AE-32	Câblage triphasé AE-10/AE-22/AE-32	SL0934
36b	Cableado monofásico AE-10/AE-22/AE-32	Wiring single phase AE-10/AE-22/AE-32	Câblage monophasé AE-10/AE-22/AE-32	SL0935
I I		I		




SAMMIC, S.A. (Sociedad Unipersonal) C/ Atxubiaga 14 · 20730 AZPEITIA







AE-10 / AE-22 / AE-32



Nota: Todas estas especificaciones están sujetas a cambio sin previo aviso, debido a la permanente mejora del producto.

Note: These specifications are subject to change without notice due to continuous improvement.

Note: SAMMIC se réserve le droit de modifier et d'améliorer ses fabrications sans préavis.