



ESQUEMA DE POTENCIA TRIFÁSICA / THREE-PHASE POWER DIAGRAM / LEISTUNGSSCHALTPLAN DREIPHASENMASCHINEN

SCHÉMA DE PUISSANCE TRIFASÉE / SCHEMA DE POTENZA TRIFASE / ESQUEMA DE POTENCIA TRIFÁSICA




ESQUEMA DE POTENCIA MONOFÁSICA / SINGLE-PHASE POWER DIAGRAM / LEISTUNGSSCHALTPLAN EINIPHASENMASCHINEN

SCHÉMA DE PUISSANCE MONOFASÉE / SCHEMA DE POTENZA MONOFASE / ESQUEMA DE POTENCIA TRIFÁSICA




CONNESSIONI SENSORI
di SICUREZZA

SENSORI di sicurezza STEM N255 GA
RISPETTARE RIF. MONTAGGIO



Tensione PRESENTE e PRONTA per AVVIO = ACCESO FISSO
Macchina in FUNZIONE = Lampeggio 0,8s.
Macchina in ALLARME = Lampeggio 2x0,2s+1s pausa.

Vedi pagina 6



UNE-EN ISO 9001