

	Denominación	Description	Denomination
<b>CA</b>	CONDENSADOR DE ARRANQUE	STARTING CONDENSER	CONDENSATEUR DE MARCHE
<b>CM</b>	CONDENSADOR PERMANENTE	PERMANENT CONDENSER	CONDENSATEUR PERMANENT
<b>C1</b>	CONTACTOR	CONTACTOR	CONTACTEUR
<b>D1</b>	REGLETA CONEXION	TERMINAL STRIP	REGLETTE DE CONNEXION
<b>D2</b>	REGLETA CONEXION INTERMEDIA	INTERMEDIATE TERMINAL STRIP	REGLETTE INTERMEDIAIRE DE CONNEXION
<b>FM</b>	FRENO MOTOR	MOTOR BRAKE	FREIN MOTEUR
<b>F4</b>	FUSIBLE	FUSE	FUSIBLE
<b>I1</b>	INTERRUPTOR GENERAL LUMINOSO	LUMINOUS MAIN SWITCH	INTERRUPTEUR GENERAL LUMINEUX
<b>I3</b>	INTERRUPTOR MAGNETICO PUERTA	DOOR MAGNETIC DETECTOR	DETECTEUR MAGNETIQUE PORTE
<b>KA</b>	RELE ARRANQUE	STARTING RELAY	RELAIS DE MARCHE
<b>K1</b>	RELE AUXILIAR	AUXILIARY RELAY	RELAIS AUXILIAIRE
<b>K2</b>	RELE FRENADO	STOP RELAY	RELAIS D'ARRÊT
<b>L3</b>	LAMPARA UV-C	UV-C LAMP	LAMPE UV-C
<b>M</b>	MOTOR	MOTOR	MOTEUR
<b>M1</b>	VENTILADOR	FAN	VENTILATEUR
<b>NTC2</b>	SONDA TEMPERATURA CUBA	TANK TEMPERATURE PROBE	SONDE TEMPERATURE CUVE
<b>PC</b>	PLACA DE CONTROL	CONTROL PANEL	PLAQUE DE COMMANDES
<b>R1</b>	RESISTENCIA DE SECADO	HEATING ELEMENTS	RESISTANCES DE CHAUFFEMENT
<b>TCL</b>	TECLADO	KEYBOARD	CLAVIER
<b>T4</b>	PROTECCION TERMICA MOTOR	MOTOR OVERLOAD PROTECTION	PROTECTION THERMIQUE MOTEUR
<b>VDR</b>	VARISTOR	VARISTOR	VARISTOR

